

CRISPO ASSEMBLY GUIDE

1



Place the wall fixation tools at 50 cm intervals and mark the wall from the screw holes.

2



Drill the points that you have already marked.

3



Place a proper plastic screw anchor to places that are drilled.

4



Screw the wall fixation tools to places that are drilled at 50 cm intervals.

5



Assemble the profile on the wall fixation tools just like in the picture.

6



Make sure that the profile nails and the fixation tool's nails are completely connected to each other and be sure that the profile sole is fixed to the floor.

7



Cut both of the two profiles 45 degrees to ensure the rotating of external corners.

8



Affix the wall fixation tools in the manner that will be closed to the corners and assemble the profiles that you cut 45 degrees on it.

9



Make sure that the profiles that are cut 45 degrees are fixed to each other completely at the external corners.

10



Cut both of the two profiles 45 degrees to ensure the rotating of internal corners.

11



Affix the wall fixation tools in the manner that will be closed to the corners and assemble the profiles that you cut 45 degrees on it.

12



Make sure that the profiles that are cut 45 degrees are fixed to each other completely at the internal corners.