







- 1** Pick the correct profile according to the tile thickness.




- 2** Apply joint and place the profiles anchor accordingly.




- 3** Press the profile until it is fixed to the joint.




- 4** Apply joint to the places where the ceramics will be placed.




- 5** Place and align the ceramics to the profile.




- 6** Cut profiles 45 degrees for external corners.




- 7** Align the profiles at the external corners and press them into the joint.




- 8** Place and align the ceramics to the profile.



- 9** Cut profiles 45 degrees for internal corners.



- 10** Align the profiles at the internal corners and press them into the joint.



- 11** Place and align the ceramics to the profile.